

OPSÆTNING OG BETJENING: FJERNBETJENING

SETTINGS: REMOTE CONTROL

Muligheder

Forbind fjernbetjening til gardin:

- Vælg den fjernbetjening og kanal der skal bruges.
- Tryk og hold On/Off knappen inde på gardinet indtil gardinet bevæger sig.
- Tryk på "op"-knappen på fjernbetjeningen.

Fjern fjernbetjening fra gardinet:

- Vælg den fjernbetjening og kanal der skal slettes.
- Tryk og hold "stop"-knappen på fjernbetjeningen inde i 5 sekunder indtil at gardinet bevæger sig.
- Tryk og hold "menu"-knappen inde bag på fjernbetjeningen i 1 sekund, indtil gardinet bevæger sig.

Ændre motorretning på gardinet:

- Vælg den fjernbetjening og kanal hvor retningen skal ændres.
- Tryk og hold "stop"-knappen inde på fjernbetjeningen i 5 sekunder indtil at gardinet bevæger sig.
- Tryk på "ned"-knappen på fjernbetjeningen.

Justere bund, mellem eller top stop:

- Kør gardinet til den position, der skal justeres.
- Tryk og hold "menu"-knappen inde bag på fjernbetjeningen indtil gardinet bevæger sig.
- Kør gardinet til den nye ønskede position.
- Tryk og hold "menu"-knappen inde på fjernbetjeningen, indtil gardinet bevæger sig.

Slet et mellem stop:

- Kør gardinet til den position, der skal slettes.
- Tryk og hold "menu"-knappen inde bag på fjernbetjeningen i 7 sekunder, indtil gardinet bevæger sig.

Indstil et mellem stop:

- Kør gardinet til den position, der skal justeres.
- Tryk på "menu"-knappen bag på fjernbetjeningen 1 gang og gardinet bevæger sig.

Nulstil gardinet til fabriksindstillinger:

- Vælg den fjernbetjening og kanal hvor gardinet skal nulstilles.
- Tryk og hold "stop"-knappen inde på fjernbetjeningen i 5 sekunder indtil at gardinet bevæger sig.
- Tryk og hold "menu"-knappen inde bag på fjernbetjeningen i 7 sekunder, Gardinet bevæger sig efter ca. 1 sekund og igen 2 gange efter ca. 7 sekunder. Gardinet er nu nulstillet.

Ændre motor bevægelse fra step til kontinuerligt og omvendt:

- Tryk og hold "stop"-knappen inde på fjernbetjeningen i 5 sekunder indtil at gardinet bevæger sig.
- Tryk på "stop"-knappen på fjernbetjeningen for at afslutte indstillingen.

Options

Connect remote control to blind:

- Select the remote control and channel to be used.
- Press and hold the On/Off button on the blind until it moves.
- Press the "up" button on the remote control.

Remove remote control from blind:

- Select the remote control and channel to be deleted.
- Press and hold the "stop" button on the remote control for 5 seconds until the blind moves.
- Press and hold the "menu" button on the back of the remote control for 1 second until the blind moves.

Change motor direction on the blind:

- Select the remote control and channel where the direction needs to be changed.
- Press and hold the "stop" button on the remote control for 5 seconds until the blind moves.
- Press the "down" button on the remote control.

Adjust bottom, middle or top stop:

- Move the blind to the position you want to adjust.
- Press and hold the "menu" button on the back of the remote control until the blind moves.
- Move the blind to the new desired position.
- Press and hold the "menu" button on the remote control until the blind moves.

Delete an intermediate stop:

- Move the blind to the position you want to delete.
- Press and hold the "menu" button on the back of the remote control for 7 seconds until the blind moves.

Set an intermediate stop:

- Move the blind to the position you want to set.
- Press the "menu" button on the back of the remote control once and the blind will move.

Reset the blind to factory settings:

- Select the remote control and channel to be reset.
- Press and hold the "stop" button on the remote control for 5 seconds until the blind moves.
- Press and hold the "menu" button on the back of the remote control for 7 seconds. The blind will move after approximately one second and then again twice after approximately 7 seconds. The blind is now reset.

Change motor movement from step to continuous and vice versa:

- Press and hold the "stop" button on the remote control for 5 seconds until the blind moves.
- Press the "stop" button on the remote control to finish the setting.